

HOW TO OPEN YOUR POOL

To open your pool you will need the following:

1. Shock
2. Algaecide
3. Chlorine Stabilizer
4. Alkalinity Increaser and Decreaser
5. PH Plus and PH Minus
6. New Sand, D.E., or Cartridge for your filter
7. Chlorine
8. Test Kit



- ☐ **STEP 1** Remove the pool cover.
- ☐ **STEP 2** Connect filter to the pool.
- ☐ **STEP 3** Remove plate from skimmer opening and remove plug from return opening.
- ☐ **STEP 4** Add water if necessary.
- ☐ **STEP 5** Clean and vacuum pool.
- ☐ **STEP 6** Test Total ALKALINITY - adjust if necessary.
- ☐ **STEP 7** Test PH Level - adjust if necessary.
- ☐ **STEP 8** Add shock at a rate of 1 gallon per 5,000 gallons of pool water.
- ☐ **STEP 9** Add ALGAECIDE at a rate of 12 ounces per 5,000 gallons of pool water.
- ☐ **STEP 10** After allowing chlorine level to decrease from SHOCK, (use test kit to make sure chlorine level is in the safe range) add CHLORINE STABILIZER at a rate of 1 LB per 5,000 gallons of pool water
- ☐ **STEP 11** Add extra concentrated chlorine at a rate of 1 OZ. per 5,000 gallons per day.

POOL SIZE ROUND	CAPACITY (GALLONS)
10 Round	2,000
12 Round	3,000
15 Round	5,000
18 Round	7,500
21 Round	10,000
24 Round	14,000
27 Round	18,000
30 Round	21,000

POOL SIZE OVAL	CAPACITY (GALLONS)
8x12, 8x14	3,000
8x19	3,500
10x15, 10x16	3,500
10x21, 12x18	5,000
12x24, 14x20	7,500
14x25, 15x24	10,000
15x30, 16x26	12,000
16x32	15,000
18x33	19,000

Staten Island's Largest Indoor Pool & Spa Showroom

STATEN ISLAND POOL & SPA

4820 Arthur Kill Rd.
Staten Island

718-605-9600